

Navigation

DESCRIPTION

Navigation is a full grain aniline dyed leather with a protective breathable finish, a smc A natural addition to any office, club house, formal or executive environment.

Average Hide Size		55 sqft	
Thickness		1.0 - 1.2 mm	
PERFORMANCE CI	HARACTERISTICS		
Light Fastness	(AATCC Method 16, Option E)	4 - 5	
Tear Strength	(ASTM D4705)	25 lbs.	
Flexing Endurance	(ASTM D2097)	Pass	
Abrasion	(ASTM D3884)	Pass	
Elongation	(ASTM D2211)	30 - 50% at 50 lbs	
Crocking	(ASTM D5053)	Wet:4 Dry:4	
Breaking Force	(ASTM D2208)	180 lbs.	
FLAMMABILITY			
Boston Fire Dept. Code (BFD 1x1)		Pass	
California Technical Bulletin 117		Pass	
Cigarette Ignition Resista	nce (NFPA 260)	Class 1	
California Technical Bulletin 133		Pass	

CLEANING INSTRUCTIONS

Far part 25.853(a) Amdt 25-116 Appendix F Part (a) (1) (ii)

Pigmented leathers have a protective finish by nature of the tanning process.

For spots and spills: Blot gently with a clean absorbent cloth. Use clear warm water and gently wipe the spill. Dry with a clean towel and allow to air dry. If water is used, use on entire area (i.e., entire seat cushion, arm rest, etc.) where the spill occurred. Do not dry with heat dryers, hair dryers, etc.

Pass

For stubborn spots and stains: Use a mild solution of Ivory soap and warm water. Apply the solution with a clean wet sponge and wash, then rinse well. Let air dry. Always test a hidden area first.

For butter, oil, or grease: Wipe excess substance with a clean, dry cloth and let stance. The spot should dissipate into the leather in a short period of time. Do not apply water

Do not use: Any saddle soaps, oils, abrasives, cleaners, soaps, furniture polish, varnish or ammonia water.

Please note: The leather with initially repel most liquids, but if left to stand over an extended period of time, they will be absorbed. Even if the spill is absorbed, it will dissipate in time and eventually diffuse any stains.